

Einzugsgebiet Colmnitzbach - PLAN-Zustand - HQ(T)

- Hochwasserrisikomanagementplan -

(Stand: Vorzugslösung 09/2016)

Name Berechnungspunkt	Gewässer	Station Lage [km]	Einzugs- gebiet [km²]	HQ(1) [m³/s]	HQ(2) [m³/s]	HQ(5) [m³/s]	HQ(10) [m³/s]	HQ(20) [m³/s]	HQ(50) [m³/s]	HQ(100) [m³/s]	HW2013 [m³/s]	Hqextrem (HW2002) [m³/s]
JR420	Colmnitzbach	3+830.0	19,549	3,487	5,539	8,624	11,004	13,322	17,048	21,000	14,339	55,361
oh. JR420	Colmnitzbach	3+835.0	17,224	3,147	4,980	7,702	9,768	11,743	15,340	18,824	12,678	49,497
Userpoint5	Colmnitzbach	4+915.0	16,630	3,068	4,848	7,480	9,466	11,349	14,913	18,274	12,287	47,864
Userpoint6	Colmnitzbach	5+720.0	16,073	2,987	4,714	7,257	9,160	10,951	14,485	17,722	11,914	46,284
JR1470	Colmnitzbach	6+565.0	15,572	2,901	4,570	7,021	8,833	10,522	14,069	17,168	11,555	44,743
JR660	Colmnitzbach	6+706.0	15,225	2,834	4,457	6,838	8,581	10,199	13,749	16,749	11,286	43,631
oh. JR660	Colmnitzbach	6+715.0	13,305	2,451	3,838	5,853	7,277	8,544	11,875	14,418	9,824	37,913
UserPoint9	Colmnitzbach	7+239.0	12,836	2,405	3,760	5,724	7,102	8,316	11,592	14,071	9,529	36,843
UserPoint10	Colmnitzbach	7+810.0	12,527	2,362	3,689	5,611	6,949	8,113	11,366	13,780	9,329	35,972
JR1510	Colmnitzbach	8+215.0	11,964	2,243	3,498	5,316	6,573	7,627	10,790	13,059	8,884	34,146
oh. JR1510	Colmnitzbach	8+265.0	11,625	2,211	3,446	5,232	6,461	7,484	10,603	12,831	8,689	33,436
UserPoint11	Colmnitzbach	8+725.0	11,096	2,138	3,327	5,045	6,217	7,179	10,205	12,342	8,332	32,049
JR1520	Colmnitzbach	9+235.0	10,505	2,014	3,131	4,750	5,855	6,749	9,614	11,608	7,873	30,156
JR1050	Colmnitzbach	9+535.0	9,738	1,865	2,894	4,390	5,418	6,244	8,876	10,707	7,280	27,853
JR1090	Colmnitzbach	9+895.0	8,891	1,735	2,687	4,113	5,304	6,541	8,406	10,002	7,242	25,650
JR1160	Colmnitzbach	10+765.0	7,976	1,587	2,453	3,740	4,809	5,914	7,592	9,043	6,512	23,458
oh. JR1160	Colmnitzbach	10+775.6	6,573	1,268	2,004	3,153	4,134	5,161	6,740	7,974	5,720	18,835
JR1210	Colmnitzbach	11+305.0	6,119	1,211	1,912	3,003	3,933	4,905	6,403	7,571	5,394	17,720
JR1240	Colmnitzbach	11+335.0	5,816	1,161	1,832	2,877	3,765	4,692	6,126	7,242	5,144	16,891
UserPoint14	Colmnitzbach	11+995.0	4,614	0,932	1,468	2,297	2,996	3,721	4,870	5,749	4,063	13,365
JR1550	Colmnitzbach	12+495.0	4,053	0,821	1,290	2,015	2,622	3,247	4,254	5,017	3,548	11,643
JR1340	Colmnitzbach	12+955.0	2,838	0,632	0,989	1,534	1,983	2,439	3,202	3,770	2,580	8,450
JR1390	Colmnitzbach	13+315.0	2,164	0,491	0,763	1,179	1,515	1,854	2,429	2,852	1,949	6,342
UserPoint15	Colmnitzbach	13+795.0	1,271	0,354	0,545	0,833	1,057	1,280	1,677	1,962	1,248	4,057
UserPoint16	Colmnitzbach	14+270.0	0,486	0,171	0,263	0,401	0,516	0,635	0,803	0,933	0,580	1,759
oh. JR420	Wiesengraben	0+000.0	2,325	0,416	0,657	1,035	1,362	1,710	2,211	2,606	1,940	6,020
JR460	Wiesengraben	1+694.3	0,584	0,394	0,620	0,975	1,281	1,606	2,074	2,442	1,810	5,583
oh. JR660	Zufluss 1	0+000.0	1,672	0,438	0,685	1,072	1,405	1,757	2,263	2,660	1,864	5,853
JR650	Zufluss 1	0+228.6	1,425	0,357	0,561	0,880	1,155	1,445	1,863	2,191	1,553	4,948
R850W850	Zufluss 2	0+000.0	0,339	0,033	0,054	0,087	0,117	0,149	0,198	0,236	0,212	0,710
oh. JR1160	Zufluss 3	0+000.0	1,403	0,319	0,452	0,597	0,687	0,764	1,097	1,400	0,935	4,340